



BGS Sæt knastaksel-monteringsværktøj | til VAG og Porsche

- til montering af knastakslerne i den rigtige position
- er absolut nødvendigt til montering af nye eller eksisterende knastakslar, kan et forsøg på at montere uden dette værktøj føre til beskadigelse af knastaksellejekonsollen og cylinderhovedet
- egnet til følgende dieselmotorer (TDI CR) af 2003: Audi, Porsche, Seat, Skoda, Volkswagen med 1.2 1.6 2.0 2.7 3.0 4.0 4.2 Common Rail motorer
- Motorkoder ASB, ASE, BKN, BKS, BMK, BNG, BPP, BSG, BTR, BUG, BUN, BVN, CAAA, CAAB, CAAC, CAAD, CAAE, CAGA, CAGB, CAGC, CAHA, CAHB, CAMA, CAMB, CANA, CANB, CANC, CAND, CAPA, CARA, CASA, CASB, CASC, CASD, CATA, CAYA, CAYB, CAYC, CAYD, CAYE, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCFA, CCFC, CCHA, CCHB, CCLA, CCMA, CCWA, CCWB, CDBA, CDCA, CDSB, CDTA, CDTB, CDUC, CDUD, CDYA, CDYB, CDYC, CEGA, CEXA, CFCA, CFFA, CFFB, CFFD, CFFE, CFGB, CFGC, CFGD, CFHA, CFHB, CFHC, CFHD, CFHE, CFHF, CFJA, CFWA, CGKA, CGKB, CGLA, CGLB, CGLC, CGLD, CGLE, CGQB, CJAA, CJCA, CJCB, CJCC, CJCD, CJGA, CJGC, CJGD, CJMA, CKDA, CKTB, CKTC, CKUB, CKUC, CKVB, CKVC, CLAA, CLAB, CLCA, CLCB, CLJA, CLLA, CLNA, CLZB, CMEA, CMFA, CMFB, CMGB, CMHA, CNEA, CNFA, CNRB, CRCA, CSHA, M05/9D (CAS), M05/9E, M05/9E (CRCA), M05/9E (CRCB)

Leveringsomfang:

- Monteringsenhed inklusive formonterede dele, skal anvendes som OEM T40094
- Knastaksel holdeklemme, skal anvendes som OEM T40095
- 2 Justeringsklemmer, skal anvendes som OEM T40096 / T40096/1
- 4 Knastakselbeslag til monteringsanordning, skal anvendes som OEM T40094/1, T40094/2, T40094/9, T40094/10
- Låseanordning til knastakselbeslag, skal anvendes som OEM T40094/11

Vægt: 13,674 kg.