4026947093192

Varenr.: BBGS9319
Tariffnummer: 82041100
Opprinnelses-land: CN

BGS Sæt knastaksel-monteringsværktøj | til VAG og Porsche

- til montering af knastakslerne i den rigtige position
- er absolut nødvendigt til montering af nye eller eksisterende knastaksler, kan et forsøg på at montere uden dette værktøj føre til beskadigelse af knastaksellejekonsollen og cylinderhovedet
- egnet til følgende dieselkøretøjer (TDI CR) af 2003: Audi, Porsche, Seat, Skoda, Volkswagen med 1.2 1.6 2.0 2.7 3.0 4.0 4.2 Common Rail motorer
- Motorkoder ASB, ASE, BKN, BKS, BMK, BNG, BPP, BSG, BTR, BUG, BUN, BVN, CAAA, CAAB, CAAC,CAAD, CAAE, CAGA, CAGB, CAGC, CAHA, CAHB,CAMA, CAMB, CANA, CANB, CANC, CAND, CAPA,CARA, CASA, CASB, CASC, CASD, CATA, CAYA, CAYB, CAYC, CAYD, CAYE, CBAA, CBAB, CBAC,CBBA, CBBB, CBDA, CBDB, CBDC, CCFA, CCFC,CCHA, CCHB, CCLA, CCMA, CCWA, CCWB, CDBA, CDCA, CDSB, CDTA, CDTB, CDUC, CDUD, CDYA, CDYB, CDYC, CEGA, CEXA, CFCA, CFFA, CFFB, CFFD, CFFE, CFGB, CFGC, CFGD, CFHA, CFHB, CFHC, CFHD, CFHE, CFHF, CFJA, CFWA, CGKA, CGKB, CGLA, CGLB, CGLC, CGLD,CGLE, CGQB, CJAA, CJCA, CJCB, CJCC, CJCD,CJGA, CJGC, CJGD, CJMA, CKDA, CKTB, CKTC, CKUB, CKUC, CKVB, CKVC, CLAA, CLAB, CLCA,CLCB, CLJA, CLLA, CLNA, CLZB, CMEA, CMFA, CMFB, CMGB, CMHA, CNEA, CNFA, CNRB, CRCA,CSHA, M05/9D (CAS),M05/9E, M05/9E (CRCA), M05/9E (CRCB)

Leveringsomfang:

- Monteringsenhed inklusive formonterede dele, skal anvendes som OEM T40094
- Knastaksel holdeklemme, skal anvendes som OEM T40095
- 2 Justeringsklemmer, skal anvendes som OEM T40096 / T40096/1
- 4 Knastakselbeslag til monteringsanordning, skal anvendes som OEM T40094/1, T40094/2, T40094/9, T40094/10
- Låseanordning til knastakselbeslag, skal anvendes som OEM T40094/11

Vekt: 13,674 kg.