



VARE NR. 65110

USER MANUAL

10W COB LED RECHARGEABLE FLOOD LIGHT

General Safety Instructions:

1. Never look directly into the LED light Source.
2. Must only be used on flat, stable surfaces.
3. Must not be immersed in water or other liquids.
4. Must not be operated with wet hands.
5. Must never be covered.
6. Must never be operated with an open housing, missing or damaged wiring compartment, or missing or damaged lens.
7. Must never be sprayed or cleaned using a steam pressure cleaner since this can damage the insulation and seals.
8. Must never be repaired by the user, repairs must only be carried out by the manufacturer or an authorized service representative.

Technical Data:

LED: 10W COB

Brightness: 400/1000 lumens

Battery: 18650 type Li-ion 7.4V 2200mAh

Working Time: 1.5hrs for 1000 lumens / 4hrs for 400 lumens.

Charging Time: 4hrs

IP65

Commissioning:

Adjust the holder to the beam angle you want.

The light has three switching stage. Press once on the On/Off switch to go to the next setting, the following setting are possible: Power saving(power on)-full power-off.

If you can keep the on/off switch pressed after initial switch-on (the light is in power saving mode) you can dim up to full power and brightness, as desired.

All light is partially charged when delivered.

Charge the product before use fully.

Please use the charger equipped with the lamp.

Please do not use the light when charging. _

Please do not use a modified or damaged charger.

Please do not leave the lamp be in charging over 24 hours.

Please do not disassemble the lamp.

Please recharge the lamp every six months when in stock.

Cleaning:

Allow the floodlight to cool down sufficiently!

Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required.

Do not use cleaners that contain abrasives or solvents.