



ProfTool

VARE NR. 86350

7.5 L LINE FILLING SYSTEM WITH RETURN LINE

The unit is designed to fill fluid in transmission, differentials and transfer cases.

Operating Instruction

1. Open the filling cap on the reservoir. Fill in dispensing fluid.
2. Tank capacity is 7.5 L.
3. Find the suitable adaptor from the selection and connect to the vehicle.
4. Connect the adaptor with dispensing hose.
5. Push-pull the dispensing handle to begin the operation.

Note: Some transmission need to return excess fluid back to filling unit. In this case, open the return line valve on the side of the pump assembly. The excess fluid will be returned and viewed in the hose.

Attention before operating

1. Viscosity Range: up to SAE 140
2. Output Capacity: 70 cc / cycle

Optional Accessory

1. Mechanical Lub Meter

AT-101		FORD
AT-102		universal nozzle
AT-103		VW;AUDI
AT-104		VW;AUDI
AT-105		VW;AUDI
AT-106		BENZ 722.9 ALTIS 2010
AT-107		Audi;VW DSG
AT-108		Audi;VW CVT

