



BGS Belt Gauge

- for adjusting initial tension of the drive belt
- can be used for all types of cars as long as technical specifications on recommended tension is provided
- 1 rotation of the adjusting nut changes the piston load approx. 10 N
- tension can be read on front and back side of the tool

Weight: 0,378 kg.