



ProfTool

VARE NR. 6545

INSTRUCTION FOR MAGBENDER

Technical Data:

Power voltage - as specified on charger
Frequency - 50/60Hz
IP rating-IP65
Battery (3.7V 2100mAh Li-ion)

Power Connection:

Verify that the voltage of the battery charger corresponds to that of the system. Use the lamp within places prescribed and governed by current regulations on workplaces and electrical systems. Check that the plug fitted on the cable is suitable for the work environment, if it is not, it must be replaced.

Main features:

- A. Flexible 180 degree folding design offering more possibilities
- B. Water resistant and very robust, IP 65
- C. Two hooks offering more light angle possibility
- D. Built-in strong magnets offering two positions (vertical and parallel)
- E. Over charge/discharge protection system. (Auto power 011 equipped)

Instructions for use:

- 1. Switch function models: 100% on-> 50% on-Off
- 2. The indicator will turn GREEN to indicate when charging is complete.
- 3. The indicator will turn RED when the battery is low, please re-charge in good time.
- 4. If the indicator does not turn CONSTANT RED, unplug the charger and then try again.

Accessories and spare parts

Use only accessories and spare parts approved by the manufacturer.

Caution:

- 1. Fully recharge the lamp until indicator turn into green before first use
- 2. Avoid looking directly into the beam
- 3. Switch off the lamp when not in use
- 4. If lamp will be stored for one month or more, please fully charge it prior to storage.

