

**TEST CERTIFICATE
& DECLARATION
OF CONFORMITY**

TO MACHINERY DIRECTIVE
2006/42/EC & 1492-2

BaTo[®]

CERTIFICATE No.

ZS-25J319

ORDER No.


7912

**Description of Goods
Round Sling
Material: 100% Polyester
Safety Factor: 7:1**

| (1) Serial No. | (2) WLL(kg) | (3) Effective Working Length(m) | (4) Color |
|-------------------------|----------------|--|--------------|
| 2501061 ~ 2501510 | 1000 | 1.5 | Purple |

**We hereby certify that the above mentioned products have been inspected
and tested to comply with the health and safety requirements of the Machinery
Directive 2006/42/EC**

lifeng Yu



Date:08/2025

Brugsanvisning for Polyester Rundsling

BATO®

WLL: 1000 kg

EWL: 1.5 m



Belastningstabel:

| SAFE LIFTING CHART - WORKING LOAD LIMIT IN Kg | | | | | | | |
|---|---------------|-------------|--------------|-------|--------|------------------|-------|
| Colour code according to EN 1492-2 | Straight Lift | Choke Hitch | Basket Hitch | | | Multi-Leg Slings | |
| | | | 0-7° | 7-45° | 45-60° | 0-45° | 0-45° |
| | | | | | | | |
| WLL Factor | 1.0 | 0.8 | 2.0 | 1.4 | 1.0 | 1.4 | 2.0 |
| WLL 1000Kg | 1000 | 800 | 2000 | 1400 | 1000 | 1400 | 2000 |
| WLL 2000Kg | 2000 | 1600 | 4000 | 2800 | 2000 | 2800 | 4000 |
| WLL 3000Kg | 3000 | 2400 | 6000 | 4200 | 3000 | 4200 | 6000 |
| WLL 4000Kg | 4000 | 3200 | 8000 | 5600 | 4000 | 5600 | 8000 |
| WLL 5000Kg | 5000 | 4000 | 10000 | 7000 | 5000 | 7000 | 10000 |
| WLL 6000Kg | 6000 | 4800 | 12000 | 8400 | 6000 | 8400 | 12000 |
| WLL 8000Kg | 8000 | 6400 | 16000 | 11200 | 8000 | 11200 | 16000 |
| WLL 10000Kg | 10000 | 8000 | 20000 | 14000 | 10000 | 14000 | 20000 |
| WLL 12000Kg | 12000 | 9600 | 24000 | 16800 | 12000 | 16800 | 24000 |
| WLL 15000Kg | 15000 | 12000 | 30000 | 21000 | 15000 | 21000 | 30000 |
| WLL 20000Kg | 20000 | 16000 | 40000 | 28000 | 20000 | 28000 | 40000 |
| WLL 30000Kg | 30000 | 24000 | 60000 | 42000 | 30000 | 42000 | 60000 |

Brugsanvisning

- Vurder løfteevne ved de forskellige løftemåder.
- Bruges mere end en båndstrop til løft, skal de være identiske.
- Hold stroppen væk fra syrer og baser.
- Beskyt stroppen mod skarpe kanter og friktion.
- Temperatur: -40° til + 100°.
- Lav aldrig knude på stroppen.

Instruktioner for inspektion

- Undersøg nøje stroppen før brug.
- Brug ikke stroppen hvis der findes noget af følgende:
 - Revner
 - Visuel inderkerne
 - Syre/base skader
 - Løse syninger
 - Varme skader